

B7 series update BIOS manual


1. Prepare bootable DOS USB stick
2. Prepare the BIOS file to be updated and unzip the BIOS file to a USB flash drive.
   (This manual, for B7 series models BIOS version: IBTMB717.AT, for example: the correct version, please the actual release version-based)
3. Connect the USB flash drive to your computer
4. Turn on the computer, enter the BIOS settings, set the USB flash drive to main boot disk, and then save the settings. The computer will automatically restart
5. After the computer restarts, it will enter DOS mode, please enter the following instructions
   AFUDOSV5 IBTMD717.AT /p /b /n [enter]
6. When input is complete, press [Enter] to update, as shown below:



7. Do not turn off the computer during the update or restart the system, this will lead to system damage
8. When the BIOS update is complete, shut down the computer and remove the USB stick
9. Turn on the system and enter the BIOS setup. Confirm the updated version and select [Save & Exit] -> [Restore Defaults] - [Yes]



10. . Once you have selected [Save & Exit] -> [Save Changes and Reset] -> [Yes] again, the computer will automatically restart.



To complete the above action, the BIOS update is finished.