How to rotate the EBOX-333x Series screen in Windows 7/ Windows 7 Embedded

1. Find EBOX-333x Series VGA driver (M2012 R8) from EBOX Download Page. Unzip the downloaded file and double click the setting.exe file then follow the instruction to install.



2. After VGA driver installation completed, type “Customize icons” in search bar.



3. Adjust Utility Application to “Show icon and notifications”.



4. A blue icon = Graphic Utility appears on screen, double click it.



5. In Graphic Utility, go to Rotation section. Select the desired rotation and press Apply to test the changes.



Note: Rotation supports the resolution up to 1280x1024 only.