Boot Update

Make a USB disk with DOS boot, unzip the package to the DOS root directory. Enter the file under DOS, input "F" and press "Enter" key. This process takes about two minutes. In this process do not do anything, do not turn off the power, waiting to appear below the blinking cursor after complete refresh you can restart.

1、Set the automatic power on

In booting process press the “DEL” into the BIOS settings， Choose the following white options, Choose“Chipset”——“PCH-IO Configuration”——“Restore AC Power Loss”——“Power on”, then press “F4” —— “YES” Save and exit.