ETHERNET DRIVER INSTALLATION GUIDE:

1. Find the yellow question mark of Ethernet in the Device Manager under the control panel/ system.

2. Select “Update Driver Software” and choose the right path, then click “ Install this driver software anyway ” when Windows Security popped out.

3. After installation completed, the Device Manager will update and show the correct device.

Note: For 2 LAN version, the 1st question mark need to be installed 1G LAN driver.

